



ALPHA METER TEMPLATE

(Including notching to allow for connectors when rear access is limited)


The Alpha Meter has been designed to be a very accurate way to measure and monitor the power delivered to and consumed by your model railway. Alpha Meter is not designed for mains use. Please note the limits of voltage and current that are clearly marked on both the packaging and the reverse side of this manual. Accuracy is 1/100th of a volt or amp if used within recommended ranges.



The Alpha Meter has been designed to be a very accurate way to measure and monitor the power delivered to and consumed by your model railway. Alpha Meter is not designed for mains use. Please note the limits of voltage and current that are clearly marked on both the packaging and the reverse side of this manual. Accuracy is 1/100th of a volt or amp if used within recommended ranges.



The Alpha Meter has been designed to be a very accurate way to measure and monitor the power delivered to and consumed by your model railway. Alpha Meter is not designed for mains use. Please note the limits of voltage and current that are clearly marked on both the packaging and the reverse side of this manual. Accuracy is 1/100th of a volt or amp if used within recommended ranges.



BE SURE TO SET PRINTER FOR FULL SIZE or ACTUAL SIZE PRINT

BE SURE TO SET PRINTER FOR FULL SIZE or ACTUAL SIZE PRINT