

Intelligent Circuit Breakers iP-CB With An Auto Reverser

IMPORTANT
Always set the iP-CB trip current with the header to be **LOWER** than the main system maximum current output.

