



# Alpha Power & Box & NCE PowerCab & Alpha Panel Option 1

**WARNING**  
Do not place any power supply in to  
the faceplate input DC power socket

